





- S1 – reset switch (pulse)
- S2 – sabotage switch
- S3 – contact keyswitch
- S4 – controlled contact keyswitch
- R1 - relay

